Opening and Closing the Polls on ClearCast



| OPENING THE POLLS | | | | |
|--|--|---|---|--|
| 1. The ClearCast scanner will be set up on a table and ready to plug in and turn on. | 2. Lift the lid/screen on the top of the scanner. 2. When the scanner. 2. Plug the power cord into the power outlet or extension cord. Listen for a single beep. 2. ClearCast will automatically print a Power On Report. | The ballot bag will be set up and attached to the ClearCast scanner with tamper evident seals. 3. Make a note of the four seal numbers and compare them to the numbers provided on your paperwork. | a. There is one seal on each side of the ballot bag that secures the bag to the scanner. b. There is a third seal on the top of the bag that secures the zipper. c. A fourth seal is a "tape seal" that secures the printer cover door on the right side of the ClearCast scanner. | 4. Tap Log In on the ClearCast screen. Image: ClearCast cl |
| 5. Tap Open Polls on the screen. | 6. The Zero Totals Tape will automatically print. 1. Confirm the name of your precinct and that zero votes are displayed for each candidate. Remove and sign the Open/Zero report and fill out the Cert. of Examination. Store the signed tape and Cert. with your election paperwork. | 8. Tap the Start Voting button to begin voting. Voting can begin at the scheduled opening time. | Insert ballot Insetter Inse | A voted ballot can be inserted into ClearCast in any direction. Image: State of the st |

©2019 Clear Ballot Group, Inc

Opening and Closing the Polls on ClearCast



